



Find your niche



VERSATILE AND MODERN



FLIP FLOP 29" BOOKCASE

HBCF2822

ASSEMBLY INSTRUCTIONS

BEFORE YOU ASSEMBLE:

- Place all parts on a clean, smooth surface to avoid scratching the parts
- Check to be sure you have all parts and hardware
- Remove all wrapping materials, including any staples & packing straps
- Keep all hardware, small parts and packaging out of reach of children

IN THE BOX:

A: Cam Pins (4)



B: Cam Locks (4)



C: Dowel Rods (2)



D: Allen Wrench



E: Inserts (4)



F: Glue



G: Bookcase Shell




H: Bookcase Top



STEP 1: Insert some Glue(F) then 2 Dowel Rods(C) into the Bookcase Top(H) in the holes marked (A). Place 4 Inserts(E) in location (B). Screw 4 Cam Pins(A) into the Inserts(E).



STEP 2: Fold out the legs and flip down the shelves on the Bookcase Shell(G). Place 4 Cam Locks(B) in the Bookcase Shell with the arrow on the locks facing up.



STEP 3: Attach Bookcase Top(H) to the Bookcase Shell(G) by inserting cam pins into locks and locking them tight using Allen Key(D). (see fig 1)

